

Name: Iaina Vmayer ID:
 Section: G Group: 01 Trimester: Spring 25 Date of Submission:

Experiment No. 01

Name of the Experiment: Determination of the refractive index of a liquid by plane mirror and pin method using a convex lens.

Theory:

If a convex lens is placed on a few drops of liquid on a plane mirror, then on squeezing the liquid into the space between the mirror and the lens, a Plano-concave liquid lens is formed. The curved surface of this liquid lens has the same radius of curvature as the surface of the lens with which it is in contact. Thus we have a combination of two lenses – one of glass and the other of liquid, which behaves as a convergent lens. If F be the focal length of the combination, then we have the relation

$$\frac{1}{F} = \frac{1}{f_1} + \frac{1}{f_2} \dots \dots \dots (1)$$

where f_1 and f_2 are the focal lengths of the convex lens and the liquid lens respectively.

Correcting for the sign of f_2 which is negative, we get

$$\frac{1}{F} = \frac{1}{f_1} - \frac{1}{f_2}$$

$$\frac{1}{f_2} = \frac{1}{f_1} - \frac{1}{F} \dots \dots \dots (2)$$

Determining F and f_1 experimentally, we can calculate f_2 from relation (2).

The focal length of the plano-concave liquid lens is also given by relation

$$\frac{1}{f_2} = (\mu - 1) \left(\frac{1}{r} - \frac{1}{r'} \right) = (\mu - 1) \frac{1}{r}$$

($r' = \infty$, the lower face of the liquid lens being a plane)

According to sign convention, both f_2 and r are negative. Thus,

$$\mu = 1 + \frac{r}{f_2} \dots \dots \dots (3)$$

Where μ is the refractive index of the liquid.

Finding r , the radius of curvature of the lower surface of the convex lens i.e. the surface in contact with the liquid, and knowing f_2 from relation (2), the refractive index of the liquid, μ can be found out by using relation (3).

Note: The radius of curvature of the surface of the lens is given by,

$$r = \frac{a^2}{6h} + \frac{h}{2}$$

Physics Laboratory

Apparatus:

- A convex lens
- A plane mirror
- Pin/pointer with its tip painted
- Spherometer
- Slide calipers
- Stand
- Some experimental liquid (water or glycerin)

Experimental Data:

(A) Measurement of h

Reading on	No. of obs.	LSR, x (cm.)	CSD	LC (cm.)	Value of CSR, $y=LC \times CSD$ (cm.)	Total reading, $x+y$ (cm.)	Mean (cm.)
Base plate	1	0	1	0.001	0.001	0.001	0.006
	2	0	11		0.011	0.011	
	3	0	8		0.008	0.008	
Lens surface	1	0.2	16		0.016	0.016	0.213
	2	0.2	9		0.009	0.009	
	3	0.2	15		0.015	0.015	

$$h = \text{Reading on lens surface} - \text{Reading on the base plate} = 0.207 \text{ cm}$$

$$\text{Measurement of 'a': Mean value of } a = \frac{a_1 + a_2 + a_3}{3} = 3.833 \text{ cm}$$

$$\text{Therefore, radius of curvature of the spherical surface, } r = \frac{a^2}{6h} + \frac{h}{2} = 11.93 \text{ cm}$$

(B) Table for the thickness of convex lens t

No. of obs.	MSR, x (cm.)	VSD	Vernier Constant, VC (cm.)	Value of VSR, $y=VC \times VSD$ (cm.)	Total reading, $x+y$ (cm.)	Mean thickness (cm.)	Instrumental Error	Correct thickness t (cm.)
1	0.8	15	0.005	0.075	0.875	0.87	0	0.87
2	0.8	13		0.065	0.865			
3	0.8	14		0.07	0.87			

Physics Laboratory

(C) Determination of the focal lengths

No. of obs.	Distance between the pin and the face of the lens (without the liquid), h_1 (cm.)	Focal length of the convex lens, $f_1 = h_1 + \frac{t}{3}$ (cm.)	Mean f_1 (cm.)	Distance between the pin and the face of the lens (with the liquid), h_2 (cm.)	Focal length of the combination, $F = h_2 + \frac{t}{3}$ (cm.)	Mean F (cm.)	Focal length of the liquid lens, $f_2 = \frac{Ff_1}{F - f_1}$ (cm.)
1	10.4	10.69	10.89	15.9	16.19	16.156	93.41
2	10.8	11.09		15.7	15.99		
3	10.6	10.89		16.0	16.29		

Calculation:

$$\therefore \mu = 1 + \frac{r}{f_2} = 1.357$$

Result:

The refractive index of the given liquid is, $\mu = 1.357$

Discussions:

Q: What is refractive index? Write down the refractive index of water and compare (% difference and % accuracy) your result.

The refractive index is a measure of how much a material slows down the speed of light compared to the speed in a vacuum. Refractive index of water is 1.33. My experimental result is 1.357

$$\text{Difference (\%)} = \frac{1.357 - 1.33}{1.33} = 0.0203 \times 100\% = 2.7\%$$

$$\text{Accuracy} = 100\% - 2.7\% = 97.3\%$$

Q: What is the physical significance of refractive index?

The physical significance of the refractive index lies in its ability to describe how light interacts with different media. It determines the speed of light in the medium and the degree of bending, as light enters or exists the medium.

Q: What is the speed of light through the liquid whose refractive index you have determined?

We know that,

$$\mu = \frac{c_0}{c_m}$$

$$\mu = 1.357$$

$$c_0 = 3 \times 10^8 \text{ ms}^{-1}$$

$$\Rightarrow c_m = \frac{c_0}{\mu} = \frac{3 \times 10^8 \text{ ms}^{-1}}{1.357}$$

$$= 2.21 \times 10^8$$

Speed of light = $2.21 \times 10^8 \text{ ms}^{-1}$ through the liquid

Q: What is radius of curvature? Is it possible to find the refractive index of the given liquid without using a spherometer?

The radius of curvature is the distance from the center of curvature to the surface of a curved lens or mirror.

Yes, the refractive index of a liquid can be determined without a spherometer by measuring critical angle of light passing from the liquid to air. Using Snell's law, the refractive index can be calculated from the critical angle without needing to measure the curvature of surfaces.

Q: Calculate the Least Count of the given spherometer.

$$\text{Least count, LC} = \frac{\text{Pitch}}{\text{Number of divisions on the CS}}$$

$$= \frac{1 \text{ mm}}{100}$$

$$= 0.01 \text{ mm}$$

$$= 0.001 \text{ cm}$$